


MAGNUM

I N D U S T R I A L

MODEL NO.: MI-93350



OPERATING MANUAL

**For Your Own Safety Read Instruction
Manual Before Operating Saw**

- a) **Wear eye protection.**
 - b) **Do not remove jammed cutoff pieces until blade has stopped.**
 - c) **Maintain proper adjustment of blade tension, blade guides, and thrust bearings.**
 - d) **Adjust upper guide just to clear workpiece.**
 - e) **Hold workpiece firmly against table.**
-
- 1. **KEEP GUARDS IN PLACE** and in working order.
 - 2. **REMOVE ADJUSTING KEYS AND WRENCHES.** Form habit of checking to see that keys and adjusting wrenches are removed from tool before turning it on.
 - 3. **KEEP WORK AREA CLEAN.** Cluttered areas and benches invite accidents.
 - 4. **DON'T USE IN DANGEROUS ENVIRONMENT.** Don't use power tools in damp or wet locations, or expose them to rain. Keep work area well lighted.
 - 5. **KEEP CHILDREN AWAY.** All visitors should be kept safe distance from work area.
 - 6. **MAKE WORKSHOP KID PROOF** with padlocks, master switches, or by removing starter keys.
 - 7. **DON'T FORCE TOOL.** It will do the job better and safer at the rate for which it was designed.
 - 8. **USE RIGHT TOOL.** Don't force tool or attachment to do a job for which it was not designed.
 - 9. **USE PROPER EXTENSION CORD.** Make sure your extension cord is in good condition.
When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating. Table below shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the cord.

Minimum gage for cord / Total length of cord in feet

| | | | 120V | 240V |
|----|-----|---|---------|---------|
| 18 | AWG | / | 25 ft. | 50 ft. |
| 16 | AWG | / | 50 ft. | 100 ft. |
| 14 | AWG | / | 100 ft. | 200 ft. |
| 12 | AWG | / | 150 ft. | 300 ft. |

- 10. **WEAR PROPER APPAREL.** Do not wear loose clothing, gloves, neckties, rings, bracelets, or other jewelry which may get caught in moving parts. Nonslip footwear is recommended. Wear protective hair covering to contain long hair.
- 11. **ALWAYS USE SAFETY GLASSES.** Also use face or dust mask if cutting operation is dusty. Daily used eyeglasses only have the limited impact resistant lenses, they are NOT safety glasses.
- 12. **SECURE WORK.** Use clamps or a vise to hold work when practice. It's safer than using your hand and it frees both hands to operate tool.

13. **DON'T OVERREACH.** Keep proper footing and balance at all times.
14. **MAINTAIN TOOLS WITH CARE.** Keep tools sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
15. **DISCONNECT TOOLS** before servicing; when changing accessories, such as blades, bits, cutters, and the like.
16. **REDUCE THE RISK OF UNINTENTIONAL STARTING.** Make sure switch is in off position before plugging in.
17. **USE RECOMMENDED ACCESSORIES.** Consult the owner's manual for recommended accessories. The use of improper accessories may cause risk of injury to persons.
18. **NEVER STAND ON TOOL.** Serious injury could occur if the tool is tipped or if the cutting tool is unintentionally contacted.
19. **CHECK DAMAGED PARTS.** Before further use of the tool, a guard or other part that is damaged should be carefully checked to determine that it will operate properly and perform its intended function-check for alignment of moving parts, binding of moving parts, breakage of parts, mounting, and any other conditions that may affect its operation. A guard or other part that is damaged should be properly repaired or replaced.
20. **DIRECTION OF FEED.** Feed work into a blade or cutter against the direction of rotation of the blade or cutter only.
21. **NEVER LEAVE TOOL RUNNING UNATTENDED. TURN POWER OFF.** Don't leave tool until it comes to a complete stop.

GROUNDING INSTRUCTIONS

CAUTION: THIS TOOL MUST BE GROUNDED WHILE IN USE TO PROTECT THE OPERATOR FROM ELECTRIC SHOCK.

In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This tool is equipped with an electric cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.

Do not modify the plug provided—if it will not fit the outlet, have the proper outlet installed by a qualified electrician.

Improper connection of the equipment-grounding conductor can result in risk of electric shock. The conductor with insulation having an outer surface that is green with or without yellow stripes is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.

Check with a qualified electrician or service personnel if the grounding instructions are not completely understood, or if in doubt as to whether the tool is properly grounded. Use only 3-wire extension cords that have 3-prong grounding type plugs and 3-hole receptacles that accept the tool's plug.

Repair or replace damaged or worn cord immediately.

115 VOLT OPERATION

As received, your tool is ready to run for 115 volt operation. This tool, when wired for 115 volts, is intended for use on a circuit that has an outlet and a plug that looks like the one shown in Fig. 1. A temporary adapter, which looks like the adapter illustrated in Fig. 2, may be used to connect this plug to a 2-pole receptacle, as shown in Fig. 2, if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet can be installed by a qualified electrician. **THIS ADAPTER IS NOT APPLICABLE IN CANADA.** The green-colored rigid ear, lug, and the like, extending from the adapter must be connected to a permanent ground, such as a properly grounded outlet box, as shown in Fig. 2.




Fig. 1




Fig. 2

230 VOLT OPERATION

If it is desired to operate this tool at 220-240 Volt. single phase operation, the following instructions must be followed:

1. Disconnect the machine from the power source.
2. This tool is supplied with 4 motor leads that are connected for 115 Volts, as shown in Fig.3. Reconnect these six motor leads for 230 Volt operation, as shown in Fig.4.
3. The 115 Volt attachment plug, supplied as standard equipment with the tool. must be replaced with a UL/CSA Listed plug suitable for 230 Volts, and rated current of the tool. This plug is illustrated in Fig.5. Contact your local Authorized Service Center or qualified electrician for proper procedures to install the plug. The tool must comply with all local and national electrical codes after the 230 Volt attachment plug is installed.
4. The drill press with a 230 Volt plug should only be connected to an outlet having the same configuration as illustrated by the grounded outlet box in Fig.5.No adapter is available or should be used with the 230 Volt plug.

IMPORTANT: IN ALL CASES (115 OR 230 VOLTS) MAKE CERTAIN THE RECEPTACLE IN QUESTION IS PROPERLY GROUNDED. IF YOU ARE NOT SURE, HAVE A REGISTERED ELECTRICIAN CHECKS THE RECEPTACLE.

CAUTION: when converting to 220 volt follow above instructions and you must change switch box with 220 volt version and order part # is P-MI-93350-148 - 220 magnetic switch




Fig. 3




Fig. 4







Fig. 5



WIRING DIAGRAM MAGNETIC SWITCH (FOR 712SG)



Part list of electrical compoments

| Item designation | Description and function | Technical data | Remarks |
|------------------|-------------------------------|---|--------------------|
| KM | Magnetic contactor | AC1-12A 600V $I_{th} = 20 \text{ A}$ | CNS 2930 BS 775 |
| FR | Overload relay | $\frac{1.6 \sim 2.6}{2.1} \text{ A}$ for 3x440V $\frac{2.8 \sim 4.5}{3.2} \text{ A}$ for 3x220V $\frac{5.0 \sim 8.0}{8} \text{ A}$ for 1x220V $\frac{12.0 \sim 18.0}{14} \text{ A}$ for 1x110V | TH-12 |
| SQ1 | Cut off limit switch | 250 Vac, 10A | UL |
| SB1 | Push-button Emergency stop | 300 Vac, 3.0A 125 Vac, 6.0A 1<> | CSA |
| SB2 SB3 | off on | AP11 1<> AP11 1<<a>> | |
| SA | Selector switch of pump | 3<<a>> for 3 phase 1<<a>> for 1 phase 600 Vac,Max | VDE UL E5579 |

Shipping Container Contents

- 1 Saw
- 1 Wheel Axle
- 2 Wheel
- 2 Split Pin
- 1 Material Stop Bar
- 1 Material Stop
- 1 Handle
- 1 Vertical Cutting Plate
- 1 Set of stand
- 1 Filter

Tools Required for Assembly

#2 Cross Point Screwdriver Pliers

Unpacking and Clean-Up

1. Finish uncrating the saw. Inspect it for shipping damage. If any damage has occurred, contact your distributor.
2. Unbolt the saw from the skid and place it on a level surface.
3. Clean rust protected surfaces with kerosene, diesel oil, or a mild solvent. Do not use cellulose based solvents such as paint thinner or lacquer thinner. These will damage painted surfaces.

Assembly

1. Place blocking under the ends of the saw base to allow stand installation. Caution: Make sure saw is steady while temporarily supported.
2. Slide wheel axles through holes in base
3. Slide wheels onto axle and fasten with pins. Bend pins to hold in place.
4. Slide material stop bar into base and secure by tightening bolt slide material stop onto bar and tighten bolt.
5. Remove transportation strap and keep for later use should the saw be moved any distance.

STARTING SAW

CAUTION: NEVER OPERATE SAW WITHOUT BLADE GUARDS IN PLACE.

Be sure the blade is not in contact with the work when the motor is started. Start the motor, allow the saw to come to full speed, then begin the cut by letting the head down slowly onto the work. **DO NOT DROP OR FORCE.** Let the weight of the saw head provide the cutting force. The saw automatically shuts off at the end of the cut.

BLADE SELECTION

A general-use high speed steel blade is furnished with this metal Cutting Band Saw. Additional blades in 4,6,8, and 10 tooth sizes are available. The choices of blade pitch is governed by the thickness of the work to be cut; the thinner the workpiece, the more teeth advised. A minimum of three(3) teeth should engage the workpiece at all times for proper cutting. If the teeth of the blade are so far apart that they straddle the work, severe damage to the workpiece and to the blade can result.

USAGE OF THE QUICK VISE

Your machine is equipped with a "quick action" vise jaw which allows you to instantly position the moveable vise jaw (B). Simply turn handwheel (A) counter clock-wise 1/2 turn and move the vise jaw (B) to the desired position. Then tighten the vise jaw (B) against the workpiece by turning hand wheel-clock wise.






Fig. 1

SPECIFICATION:

| | |
|-----------------|---|
| CAPACITY 90° | ● 180MM (7") ■ 180x250MM (7"x10") ■ 55x280MM (2.1"x11") |
| CAPACITY 45° | ● 105MM (4.1") ■ 120x100MM (4.7"x4") |
| BLADE SIZE | 19MMX0.9MMX2360MM (3/4"X0.032"X93") |
| MOTOR | 1HP 60HZ 1720RPM , 1HP 50HZ 1430RPM |
| BLADE SPEED | 3 SPEED 39.66.82MPM (125.215.270FPM) |
| MITER SCALE | 0° , -45° DEGREE |
| AUTO SETTING AT | 0° , 15° , 30° , 45° DEGREES |
| PACKING | 50"X22.5"X42.5" |
| WEIGHT | N.W./G.W. 180/210KGS 396/462LBS |



Vertical Cutting Plate Assembly

Note: These steps are only necessary if using the bandsaw in the vertical mode.

WARNING

Disconnect bandsaw from the power source before making any repairs or adjustments!

Failure to comply may cause serious injury!

1. Disconnect the bandsaw from the power source.
2. Raise the arm to the vertical position and lock in place by turning the hydraulic cylinder valve to the off position.
3. Remove two screws (A, Fig. 2) and remove the deflector plate (B).
4. Guide blade through slot in table and fasten with two screws. See Fig. 3




Fig. 2

Coolant Tank Preparation

Use of a water-soluble coolant will increase cutting efficiency and prolong blade life. Do not use black cutting oil as a substitute. Change cutting oil often and follow manufacturers instructions as to its uses and precautions.

1. Disconnect machine from the power source.
2. Remove coolant return hose from tank cover.
3. Slide tank out of saw base and carefully remove lid containing coolant pump.
4. Fill tank to approximately 80% of capacity.
5. Place lid back onto tank and place tank assembly back into base.
6. Replace return hose back into hole in tank lid.




Fig. 3

ELECTRIC BOX

1. Emergency Stop Button-depress to stop all machine function immediately.
2. Coolant Switch-turn arrow to "I" to turn on flow of coolant. Turn arrow to "O" to stop flow of coolant.
3. Start Button - depress to start bandsaw.
4. Stop Button - depress to stop bandsaw.




Fig. 4

Changing Blade Speed

To set speed for 1 to 3 position.

1. Disconnect machine from the power source.
2. Turn the handle (A, Fig. 5) with one hand, and use the other hand to give a pull at the blade. The blade speed can be freely set at the position marked 1, 2, or 3. (B).
3. While being set at the position 1, speed comes to 125FPM which is for the cut of Tool steel, Stainless steel, Hard cast iron, Alloy steel, and Hard Bronze.
4. Position 2, speed comes to 215FPM for the cut of mild steel, soft cast iron, medium hard Bronze, hard Aluminum, and Plastics.
5. Position 3, speed up to 270FPM for Plastics, soft, or medium soft Alum, Wood, and other light materials.
6. Connect machine to the power source.

Note: There is the speed selection chart posted on the above of the gear box.





Fig. 5



Hydraulic Feed Selector Operation

The hydraulic feed selector is used to control the blade feed rate and to lock the arm in the vertical position. To increase the feed rate, turn knob (1), (Fig. 6) counter-clockwise. To decrease the feed rate, turn knob (1) clockwise. To turn off the flow of hydraulic fluid, turn lever as in figure 6. To turn the hydraulic cylinder on, raise lever (2) to the 12 o'clock position.




Fig. 6

Adjusting Blade Tension



WARNING

Disconnect machine from the power source!
Blades are sharp! Use extra care when
removing, installing or adjusting!
Failure to comply may cause serious injury!

Blade tension is important to the proper operation of the saw. Proper blade tension is 22,000 to 25,000 lbs. per square inch as measured on a blade tension gauge.

To set the blade tension without the use of a blade tension gauge:

1. Install blade between wheel and insert blade between bearings on blade guides.
2. Tension blade slightly to remove any sag in blade between blade wheels.
3. Turn blade tension knob (A, Fig. 7) one and three quarter to two revolutions clockwise. This equals approximately 23,000 lbs. of blade tension.

CAUTION!

Do not over tighten blade. This may cause blade to stretch and warp.




Fig. 7

4. After blade has been completely installed, close covers, connect to the power source, and run saw for two to three minutes so blade can seat properly.
5. Disconnect machine from the power source. Open cover and loosen blade just until it begins to sag.
6. Tighten blade until it becomes straight between blade wheel and all sag has been eliminated.
7. Tighten blade by turning blade tension wheel two full revolutions. Blade is now properly tensioned and ready for use.
8. Close covers and connect machine to the power source.

Adjusting Blade Tracking



WARNING

Blade tracking adjustment requires running the saw with the back cover open. This adjustment must be completed by qualified persons only!

Failure to comply may cause serious injury!

Note: Before making any tracking adjustments, try a new blade. Warped blades will not track.

Blade tracking has been set at the factory and should not require adjustment. If a tracking problem occurs, adjust the machine as follows:

1. Move saw arm to the vertical position and lock in place by turning off the hydraulic cylinder valve.
2. Confirm that blade tension is set properly. To adjust, see section titled "Adjusting Blade Tension".
3. Open back cover by loosening lock screws.
4. Run saw and observe blade. Blade should run next to but not tightly against wheel flange.
5. Loosen bolts (A, Fig.8)
6. Turn set screw (B) while observing blade tracking on wheel. Turn set screw clockwise to track blade closer to the wheel flange. Turn set screw counter-clockwise to track blade away from the wheel flange.
7. Once tracking is set, tighten bolts (A).




Fig. 8



Warning

Anti-tilt Post

Don't try to swivel saw head to 45° then raise saw arm to vertical position to perform vertical cutting that will cause band saw falling down damaged or operator injured.

Install the attached support post by tighten two screws on the base as picture, after unpacking shipping crate for prevent any incorrect operating as above situation.

Vertical cutting only use at 90° that is correct way to avoid any damaged.



Cutting Angles Adjustment

1. Loosen handle knob (A, Fig.9).
2. Rotate the upper assembly along the miter scale (A, Fig.10) to desired cutting angle. This saw allows cutting angle from 0 to 45 degree, and has settings at 2 points (0 and 45 degree).
3. Tighten handle knob (A, Fig.9).




Fig. 9

Adjusting Blade Guide Bearings

CAUTION !

This machine is designed and intended for use with blades that are 3/4" wide by .032" thick by 93" long. Use of blades with different specifications may cause inferior performance.

1. Disconnect machine from the power source.
2. Raise arm to vertical position and lock in place by turning off the hydraulic cylinder valve.
3. Loosen hex cap screw (A, Fig.11) and adjust assembly so that back roller bearing is approximately .003"- .005" from the back of the blade.
4. Turn nut (B) to adjust eccentric bearing snug to the blade. Blade should still move up and down freely when grasped as in Fig.8.
Warning! Make sure power is disconnected and hands are protected before handling blade. Be sure that blade teeth do not interfere with the roller bearings.
5. Repeat for other blade guide assembly.
6. Connect machine to the power source.




Fig. 10




Fig. 11

Prior to Operation

1. Check to see blade tooth direction matches diagram on saw body.
2. Check to see that blade is properly seated on wheels after proper tension has been applied.
3. Set blade guide roller bearings snug against blade See "Adjusting Blade Guide Bearings" for more detail.
4. Check for a slight clearance between the back up rollers and the back of blade.
5. Position both blade guides as close to work as possible.
6. Select proper speed and feed rate for material being cut.
7. Material to be cut must be held securely in vise.
8. Check to see that coolant level is adequate.
9. Do not start cut on a sharp edge.
10. Keep machine lubricated See "Lubrication" section.

Changing Blades



WARNING

Never operate this saw unless all blade guards are installed and in proper working order !
Never adjust blade brush while machine is running !
Failure to comply may cause serious injury !

CAUTION !

This machine is designed and intended for use with blades that are 19 mm wide by 0.9mm thick by 2360mm long.
Use of blades with different specifications may cause inferior performance.

1. Disconnect machine from the power source.
2. Raise saw arm to vertical position and lock in place by turning hydraulic cylinder off.
3. Remove red blade guard assembly (A, Fig.12) by removing two screws (B).



WARNING

It is essential this guard be installed after the new blade has been fitted !
Failure to comply may cause serious injury !

4. Remove brush assembly (C) by removing two screws (D).
5. Loosen blade tension by turning blade tension knob counter-clockwise.
6. Carefully remove old blade. **Caution: blade teeth are sharp. Handle with care.**
7. Install new blade by placing blade between blade guides first. Make sure blade teeth face the same direction as indicated on the label found on the saw arm.





Fig. 12

TROUBLE SHOOTING CHART

| SYMPTOM | POSSIBLE CAUSE (s) | CORRECTIVE ACTION |
|------------------------------------|--|--|
| Excessive Blade Breakage | <ol style="list-style-type: none"> 1. Incorrect blade tension 2. Incorrect speed or feed 3. Material loose in vise 4. Blade rubs on wheel flange 5. Teeth too coarses for material 6. Teeth in contact with work before sawis started 7. Misallgned guides 8. Blade too thick for wheel diameter 9. Cracking at weld | <ol style="list-style-type: none"> 1. Adjust to where blade just does not slip on wheel. 2. Check Machinist Handbook 3. Clamp work securely 4. Adjust wheel alignment 5. Check Machinist Handbook for recomm-anded blade type 6. Place blade in contact work after motor is started 7. Adjust 8. Use thinner blade 9. Make longer annealing cycle |
| Permature Blade Dulling | <ol style="list-style-type: none"> 1. Teeth too corase 2. Too much speed 3. Inadequate feed pressure 4. Hard spots or scale in/on material 5. Work hardening of material (especially stainless steel) 6. Blade installed backwards 7. Insufficient blade tension | <ol style="list-style-type: none"> 1. Use finer tooth blade 2. Try next lower speed 3. Decrease spring tension on side of saw 4. Reduce speed increase feed pressure (Scale) Increase feed pressure (Hard Spots) 5. Increase feed pressure by reducing spring tension. 6. Remove blade twist inside out and reinstall blade. 7. Increase tension to proper level |
| Bad Cuts (crooked) | <ol style="list-style-type: none"> 1. Work not square 2. Feed pressure too great 3. Guide bearing not adjusted properly 4. Inadequate blade tension 5. Blade guides spaced out too much 6. Dull blade 7. Speed incorrect 8. Blade guide assembly loosen 9. Blade guide bearing assembly loose 10. Blade tracks too far away from wheel flanges | <ol style="list-style-type: none"> 1. Adjust vise to be square with blade Always clamp work tightly in vise. 2. Reduce pressure by increasing spring tension on side of saw. 3. Adjust guide bearing to 001 greater than max. thickness. including weld of the saw. 4. Increas adequate tension a little at a time. 5. Move guide as close to work as possible. 6. Replace blade 7. Check manual for recommended speeds 8. Tighten 9. Tighten 10. Retrack blade according to operating instructions. |
| Bade cuts (Rough) | <ol style="list-style-type: none"> 1. Too much speed or feed 2. Blade is too coarse | <ol style="list-style-type: none"> 1. Reduce speed and feed 2. Replace with finer blade |
| Blad is twisting | <ol style="list-style-type: none"> 1. Cut is binding blade 2. Too much blade tension | <ol style="list-style-type: none"> 1. Decrease feed pressure 2. Decrease blade tension |
| Unusual Wear on Side/Back of Blade | <ol style="list-style-type: none"> 1. Blade guides worn 2. Blade guide bearings not adjusted properly. 3. Blade guide bearing bracket is loosen | <ol style="list-style-type: none"> 1. Replace 2. Adjust as per operators manual 3. Tighten |
| Teeth Ripping from blade | <ol style="list-style-type: none"> 1. Tooth Too coarse for work 2. Too heavy feed / too slow feed 3. Vibrating work place 4. Gulleets loading | <ol style="list-style-type: none"> 1. Use finer tooth blade 2. Increase feed pressure and/or speed 3. Clamp work Securely 4. Use coarse tooth blade or brush to remove chips |
| Motor Running too Hot | <ol style="list-style-type: none"> 1. Blade tension too high. 2. Blade is too coarse for work (Pipes especially) 3. Blade is too fine for work (Heavier, soft materially) 4. Gear not aligned properly 5. Idler wheel needs lubrication | <ol style="list-style-type: none"> 1. Reduce tension on blade 2. Use finer blade 3. Use coarser blade 4. Adjust gears so that worm is in center or gear 5. Oil bearing/ shaft on idler wheel |



PARTS LIST FOR MI-93350

| ITEM NO. | DESCRIPTION | SIZE | Q'ty |
|---------------|-----------------------|------------|------|
| MI-93350-01 | BOTTOM DISH | | 1 |
| MI-93350-01-1 | HEX. HD. SCREW | 3/8X1-1/2 | 2 |
| MI-93350-01-2 | NUT | 3/8 | 2 |
| MI-93350-02 | FEET-STAND (RIGHT) | | 1 |
| MI-93350-03 | FEET-STAND (LEFT) | | 1 |
| MI-93350-04 | PANEL | | 2 |
| MI-93350-05 | HOSE | 1" | 1 |
| MI-93350-06 | PUMP | | 1 |
| MI-93350-08 | ROUND HD. SCREW | 1/4X1/2 | 4 |
| MI-93350-09 | HOSE FITTING | | 1 |
| MI-93350-10 | HOSE CLAMP | | 1 |
| MI-93350-11 | HOSE | 5/16 | 1 |
| MI-93350-12 | COOLANT TANK | 6L | 1 |
| MI-93350-13 | HAND | | 1 |
| MI-93350-14 | HEX. HD. SCREW | 5/16X3/4 | 4 |
| MI-93350-15 | WASHER | 5/16 | 4 |
| MI-93350-15-1 | SPRING WASHER | 5/16 | 4 |
| MI-93350-16 | WHEEL | 8" | 2 |
| MI-93350-16-1 | WASHER | | 1 |
| MI-93350-18 | WHEEL SHAFT | | 1 |
| MI-93350-19 | SPRING PIN | | 2 |
| MI-93350-20 | HEX. HD. SCREW | 5/16X1-1/2 | 4 |
| MI-93350-21 | WASHER | 5/16 | 8 |
| MI-93350-21-1 | SPRING WASHER | 5/16 | 4 |
| MI-93350-22 | NUT | 5/16 | 4 |
| MI-93350-23 | DOOR | | 1 |
| MI-93350-24 | PIN | | 2 |
| MI-93350-25 | LOCK KNOB | 1/4X3/4 | 1 |
| MI-93350-26 | FILTER | 5/16X1-1/2 | 1 |
| MI-93350-27 | BRACKET | | 1 |
| MI-93350-28 | BRACKET | | 1 |
| MI-93350-29 | CHIP GUIDE PLATE | | 1 |
| MI-93350-30 | HEX HD, SCREW | 5/16X3/4 | 2 |
| MI-93350-31 | NUT | 5/16 | 2 |
| MI-93350-31-1 | SPRING WASHER | 5/16 | 2 |
| MI-93350-32 | WASHER | 5/16 | 2 |
| MI-93350-32-1 | HEX, HDSCREW | 5/16 | 2 |
| MI-93350-33 | SPRNG WASHER | 5/16 | 2 |
| MI-93350-34 | NUT | 5/16 | 2 |
| MI-93350-35 | LOW BASE OF DISC | | 1 |
| MI-93350-36 | HEX. SOCKET CAP SCREW | M10X20 | 4 |
| MI-93350-37 | SWIVEL BASE | | 1 |
| MI-93350-43 | BOTTOM SUPPORT | | 1 |
| MI-93350-44 | HEX. HD SCREW | 5/16X1 | 3 |
| MI-93350-45 | SPRING WASHER | 5/16 | 3 |
| MI-93350-46 | SUPPORT ROD | | 1 |

PARTS LIST FOR MI-93350

| ITEM NO. | DESCRIPTION | SIZE | Q'ty |
|---------------|-----------------------|------------|------|
| MI-93350-47 | HYDRAULIC CYLINDER | | 1 |
| MI-93350-48 | CYLINDER COVER | | 1 |
| MI-93350-49 | ROUND HD. SCREW | 1/4X1/4 | 2 |
| MI-93350-50 | SUPPORT PLATE | | 1 |
| MI-93350-51 | HEX. HD. SCREW | 3/8X1 | 2 |
| MI-93350-52 | SPRING WASHER | 3/8 | 2 |
| MI-93350-53 | HEX.HD. SCREW | M12X40 | 1 |
| MI-93350-54 | NUT | M12 | 1 |
| MI-93350-55 | SPLASH GUARD | | 1 |
| MI-93350-56 | HEX. HD SCREW | 5/18X384 | 2 |
| MI-93350-60 | WASHER | | 2 |
| MI-93350-61 | BUSHING | | 1 |
| MI-93350-62 | SUPPORT SHAFT | | 1 |
| MI-93350-63 | PIVOT ARM | | 1 |
| MI-93350-64 | NUT | 5/16 | 1 |
| MI-93350-65 | HEX HD. SCREW | 5/16X1-1/2 | 1 |
| MI-93350-66 | NUT | 3/8 | 1 |
| MI-93350-67 | HEX HD. SCREW | 3/8X1-3/4 | 1 |
| MI-93350-68 | PLATE | | 1 |
| MI-93350-69 | HEX HD. SCREW | 3/8X1-1/2 | 2 |
| MI-93350-70 | SPRING WASHER | 3/8 | 2 |
| MI-93350-72 | UPPER OF DISC | | 1 |
| MI-93350-73 | HEX. SOCKET CAP SCREW | M10X20 | 4 |
| MI-93350-74 | LOCK HANDLE | 3/8X50 | 1 |
| MI-93350-75 | BRONZE BUSHING | | 1 |
| MI-93350-76 | THRUST SHAFT | | 1 |
| MI-93350-77 | SCALE | | 1 |
| MI-93350-77-1 | RIVET | 2.3x4mm | 2 |
| MI-93350-78-1 | RIVET | 2.3x4mm | 1 |
| MI-93350-78 | ANGLE INDICATOR | | 1 |
| MI-93350-81 | TABLE | | 1 |
| MI-93350-82 | HANDLE WHEEL ASSEMBLY | | 1 |
| MI-93350-83 | SET SCREW | 5/16X3/8 | 1 |
| MI-93350-84 | LEAD SCREW | | 1 |
| MI-93350-85 | KEY | 5MM | 1 |
| MI-93350-86 | LEAD SCREW BRACKET | | 1 |
| MI-93350-87A | ACME NUT ASSEMBLY | | 1 |
| MI-93350-92 | HEX. SOCKET CAP SCREW | M12X30 | 2 |
| MI-93350-93 | SPRING WASHER | 1/2 | 2 |
| MI-93350-94 | TOP SUPPORT | | 1 |
| MI-93350-95 | HEX HD. SCREW | 5/16X3/4 | 2 |
| MI-93350-96 | SPRING WASHER | 5/16 | 2 |
| MI-93350-97 | 90' SUPPORT | | 1 |
| MI-93350-98 | HEX. HD. SCREW | M10X40 | 1 |
| MI-93350-99 | NUT | M10 | 1 |
| MI-93350-100 | SPRING WASHER | 3/8 | 2 |

PARTS LIST FOR MI-93350

| ITEM NO. | DESCRIPTION | SIZE | Q'ty |
|----------------|---------------------------|------------|------|
| MI-93350-101 | HEX, HD, SCREW | 3/8X1-1/4 | 2 |
| MI-93350-102 | LIMIT SWITCH | | 1 |
| MI-93350-103 | UMIT SWITCH COVER | | 1 |
| MI-93350-104 | SCREW CAP | 3/16X3/8 | 2 |
| MI-93350-105 | HEX.HD SCREW | 5/16X3/4 | 1 |
| MI-93350-106 | WASHER | 5/16 | 1 |
| MI-93350-107 | THUMB SCREW | | 1 |
| MI-93350-108 | STOP BRACKET | | 1 |
| MI-93350-109 | WORK STOP | | 1 |
| MI-93350-110 | SPRING WASHER | 5/16 | 2 |
| MI-93350-111 | HEX. HD. SCREW | 5/16X3/4 | 1 |
| MI-93350-112 | STOP ROD | | 1 |
| MI-93350-114 | HEX, HD, SCREW | M12X35 | 2 |
| MI-93350-115 | SPRING WASHER | 1/2 | 2 |
| MI-93350-116 | REAR VISE | | 1 |
| MI-93350-117 | HEX HD, SCREW | 3/8X1-1/2 | 1 |
| MI-93350-118 | SPRING WASHER | 3/8 | 2 |
| MI-93350-119 | SCREW HANDLE | | 1 |
| MI-93350-120 | WASHER | 3/8 | 1 |
| MI-93350-121 | FRONT VISE | | 1 |
| MI-93350-122 | NUT | 3/8 | 2 |
| MI-93350-123 | HEX. HO SCREW | 3/8X3/4 | 1 |
| MI-93350-124 | SPRING BRACKET | | 1 |
| MI-93350-125 | SPRING ADJUSTING ROD | 3/8 | 1 |
| MI-93350-126 | SPRING | | 1 |
| MI-93350-127 | SAW BOW | | 1 |
| MI-93350-127-1 | HEX, HD, SCREW | 5/16X1-1/4 | 4 |
| MI-93350-127-2 | SPRING WASHER | 5/16 | 4 |
| MI-93350-127-3 | ADJ. SCREW | 1/4X3/8 | 2 |
| MI-93350-129 | VENT PLUG | | 1 |
| MI-93350-130 | KEY | 6/20 | 1 |
| MI-93350-131 | HEX HD. SCREW | 3/8X7/8 | 1 |
| MI-93350-131-1 | SPRING WASHER | 3/8 | 1 |
| MI-93350-131-2 | WASHER | 3/8X35X4 | 1 |
| MI-93350-133 | BLADE WHEEL (REAR) | | 1 |
| MI-93350-134 | BLADE | | 1 |
| MI-93350-135 | BLADE BACK COVER | | 1 |
| MI-93350-136 | WHEEL COVER | | 1 |
| MI-93350-137 | PLUM SCREW | | 2 |
| MI-93350-137-1 | WASHER | 1/4 | 4 |
| MI-93350-138 | WASHER | 1/4 | 4 |
| MI-93350-139 | ROUND HD. SCREW | 1/4X1/2 | 4 |
| MI-93350-140 | GUIDE ADJUSTABLE KNOB | 3/8X1-1/4 | 2 |
| MI-93350-141 | ADJUSTABLE BRACKET (REAR) | | 1 |
| MI-93350-142 | BALL BEARING | 608ZZ | 2 |
| MI-93350-143 | BEARING PIN | 8MM | 2 |


PARTS LIST FOR MI-93350

| ITEM NO. | DESCRIPTION | SIZE | Q'ty |
|----------------|--------------------------------|------------|------|
| MI-93350-144 | BLADE ADJUSTABLE SEAT (REAR) | | 1 |
| MI-93350-144-1 | BLADE ADJUSTABLE SEAT (FRONT) | | 1 |
| MI-93350-145 | NUT | 3/8X24UNF | 4 |
| MI-93350-145-1 | SPRING WASHER | 3/8 | 4 |
| MI-93350-146 | ECCENTRIC SHAFT ASSEMBLY | | 2 |
| MI-93350-146-1 | CENTER SHAFT ASSEMBLY | | 2 |
| MI-93350-147 | VERTICAL CUTTING PLATE | OPTION | 1 |
| MI-93350-147-1 | VERTICAL CUTTING PLATE ISMALLI | | 1 |
| MI-93350-147-2 | HD. SCREW | 1/4X1/2 | 2 |
| MI-93350-148 | MAGNETIC SWITCH | | 1 |
| MI-93350-149 | WASHER | 5/16 | 2 |
| MI-93350-150 | SPRING WASHER | 5/16 | 2 |
| MI-93350-151 | HEX. SOC. SCREW | 5/16X1-1/8 | 2 |
| MI-93350-152 | TOP SUPPORT | | 1 |
| MI-93350-153 | HEX. HD. SCREW | 3/8X1-1/4 | 2 |
| MI-93350-154 | SPRING WASHER | 3/8 | 2 |
| MI-93350-155 | NUT | 3/8 | 2 |
| MI-93350-156 | ROUND HD. SCREW | 1/4X1/2 | 2 |
| MI-93350-157 | WASHER | 1/4 | 2 |
| MI-93350-158 | BRUSH HOLDER | | 1 |
| MI-93350-159 | SET SCREW | 1/4X1/4 | 1 |
| MI-93350-160 | FIXED BUSHING | | 1 |
| MI-93350-161 | BRUSH | 1-1/2X6MM | 1 |
| MI-93350-162 | SUPPORT ROD | | 1 |
| MI-93350-163 | NOZZLE COCK | | 1 |
| MI-93350-164 | NOZZLE COCK SUPPORT | | 1 |
| MI-93350-165 | SET SCREW | 1/4X1/2 | 1 |
| MI-93350-166 | HEX. SOC. SCREW | 5/16X1-1/8 | 1 |
| MI-93350-166-1 | SPRING WASHER | 5/16 | 1 |
| MI-93350-167 | HEX. SOC. SCREW | 5/16X1 | 1 |
| MI-93350-168 | SPRING WASHER | 5/16 | 1 |
| MI-93350-169 | WASHER | 5/16 | 1 |
| MI-93350-170 | VALVE | | 1 |
| MI-93350-171 | HOSE CLAMP | 13MM | 1 |
| MI-93350-172 | BRACKET | | 1 |
| MI-93350-172-1 | HEX HD. SCREW | 1/4X1/2 | 1 |
| MI-93350-172-2 | SPRING WASHER | 1/4 | 1 |
| MI-93350-172-3 | WASHER | 1/4 | 1 |
| MI-93350-173 | ADJUSTABLE BRACKET (FRONT) | | 1 |
| MI-93350-174 | BLADE GUARD | | 1 |
| MI-93350-175 | ROUND HD. SCREW | 3/16X1/4 | 2 |
| MI-93350-176 | SLIDING GUIDE PLATE | | 2 |
| MI-93350-177 | HEX. HD. SCREW | 1/4X1/2 | 4 |
| MI-93350-178 | BLADE TENSION SLIDING BLOCK | | 1 |
| MI-93350-179 | SET SCREW | 5/16X3/4 | 1 |
| MI-93350-180 | HEX. HD. SCREW | 5/16X1-1/2 | 2 |

PARTS LIST FOR MI-93350

| ITEM NO. | DESCRIPTION | SIZE | Q'ty |
|----------------|-----------------------|----------|------|
| MI-93350-181 | SLIDING DRAW BLOCK | | 1 |
| MI-93350-182 | BEARING BUSHING | | 1 |
| MI-93350-183 | BALL BEARING | 6203ZZ | 2 |
| MI-93350-184 | BLADE WHEEL (FRONT) | | 1 |
| MI-93350-185 | WASHER | 5/16 | 1 |
| MI-93350-185-1 | SPRING WASHER | 5/16 | 1 |
| MI-93350-186 | HEX. HD. SCREW | 5/16X3/4 | 1 |
| MI-93350-187 | WASHER | 3/8 | 1 |
| MI-93350-188 | GUIDE ADJUSTABLE KNOB | | 1 |
| MI-93350-189 | SUPPORT PLATE | | 1 |
| MI-93350-190 | WASHER | 1/4 | 2 |
| MI-93350-191 | HEX. HD. SCREW | 1/4X3/8 | 2 |
| MI-93350-192-1 | MOTOR | | 1 |
| MI-93350-192-2 | STRAIN RELIEF | | 1 |
| MI-93350-192-3 | HEX, HD, SCREW | 8X25MM | 2 |
| MI-93350-192-4 | SPRING WASHER | 8MM | 2 |
| MI-93350-193 | KEY | 5MM | 1 |
| MI-93350-194-1 | WORM SHAFT | | 1 |
| MI-93350-195-1 | GEAR FLANGE | | 1 |
| MI-93350-195-2 | HEX. SOC. SCREW | 6X20MM | 1 |
| MI-93350-196N | GEAR BOX | | 1 |

MI-93350-196N GEAR BOX



PART LIST FOR MI-93350-196N GEAR BOX

| PART NO. | DESCRIPTION | Q'TY |
|-----------------|-------------------------|------|
| MI-93350-196N1 | Drain Plug | 1 |
| MI-93350-196N2 | Gear Box | 1 |
| MI-93350-196N3 | Adjustable Bracket | 1 |
| MI-93350-196N4 | Indicator Plate | 1 |
| MI-93350-196N5 | Position Pin | 1 |
| MI-93350-196N6 | Compression Spring | 1 |
| MI-93350-196N7 | Plastic Handle | 1 |
| MI-93350-196N8 | Socket Set Screws | 2 |
| MI-93350-196N9 | Hex Socket Flat Screw | 3 |
| MI-93350-196N10 | Gasket | 1 |
| MI-93350-196N11 | Drive Gear Assembly | 1 |
| MI-93350-196N12 | Drive Shaft | 1 |
| MI-93350-196N13 | Key | 1 |
| MI-93350-196N14 | C-Ring | 3 |
| MI-93350-196N15 | Ball Bearing | 2 |
| MI-93350-196N16 | Ball Bearing | 5 |
| MI-93350-196N17 | Transfer Gears Assembly | 1 |
| MI-93350-196N18 | Set Pins | 2 |
| MI-93350-196N19 | Gear Box Cover | 1 |
| MI-93350-196N20 | Oil Seal | 1 |
| MI-93350-196N21 | Hex. Soc. Cap Screw | 5 |
| MI-93350-196N22 | Motor Cover | 1 |
| MI-93350-196N23 | Worm Shaft | 1 |
| MI-93350-196N24 | O-Ring | 1 |
| MI-93350-196N25 | Gear Flange | 1 |
| MI-93350-196N26 | Hex. Soc. Cap Screw | 1 |
| MI-93350-196N27 | Spring Washer | 2 |
| MI-93350-196N28 | Hex. Head Screw | 2 |
| MI-93350-196N29 | Spacer Bushing | 1 |
| MI-93350-196N30 | Worm Gear | 1 |
| MI-93350-196N31 | Key | 1 |
| MI-93350-196N32 | Input Gears | 1 |